Sunset Inlet ARC November 2020

## **Dock Box Specification Sheet**

The approved dock box is the Taylor Made Products Model 83561 Stow N Go Triangle Dock Box.

Special instructions for installation of the dock box :

- 1. It can be mounted on the angled corner of any dock with minimal impact to dock access (see dock picture below). It does not require drilling any holes in the seawall bulkhead.
- 2. The wood on the dock must be treated with sealant before dock box installation.
- 3. Installation must be done by a licensed & insured contractor. The contractor license and insurance information must be submitted to Watson prior to installation.
- 4. Homeowner assumes full responsibility for any damage done to the dock in the process of installation or removal.
- 5. One dock box allowed per slip

The box must be mounted on the wooden dock structure on the angled section of the dock (see picture – the approximate location of the box is marked in blue). The box can be mounted so that up to 6 inches are cantilevered over the dock edge, making the dock footprint even smaller. Stainless steel bolts and hardware should be used.

Link to Amazon.com for purchase:

https://www.amazon.com/Taylor-Made-Products-83561-Triangle/dp/B000MUD4TM/ref=pd\_ybh\_a\_25?\_encoding=UTF8&psc=1&refRID=ZNXJCTYC6RGNGMN0XPQQ



